


DING-A-LING

ROCKY

INSTRUCTION SHEET


• DO NOT THROW THIS SHEET AWAY. READ ALL INSTRUCTIONS CAREFULLY.

HOW TO LOAD ROCKETS




PUSH ROCKETS ALL THE WAY INTO HOLES.

HOW TO PLAY WITH ROCKY



TO SHOOT ROCKETS, PUSH TAB ON ROCKY'S HEAD FORWARD AS SHOWN.



IMPORTANT

FOR BEST RESULTS ON SPACE SKYWAY SETS, PUT A SMALL AMOUNT OF VASELINE® ALL ALONG LEDGES BETWEEN DING-A-LING'S FEET, AS SHOWN. BE SURE TO ADD MORE VASELINE® WHEN NEEDED.



©1971 TOPPER CORPORATION, ELIZABETH, N.J. 07206

3028-0030

PRINTED IN U.S.A.